

Jøtul Gas Atra 740 SS

Jøtul Gas Atra 740 SS

Installation and Operating Instructions



Monterings- og bruksanvisningen må oppbevares under hele produktets levetid. These instructions must be kept for future references. Wir empfehlen Ihnen, die Montage- und Bedienungsanleitung für spätere Zwecke sorgfältig aufzubewahren. Ce document doit être conservé pendant toute la vie de l'appareil.

Installation signature form

With proper usage and maintenance, this fireplace will serve its owner adequately for many years. Please contact your Jøtul dealer for assistance if any problems should arise with your Jøtul fireplace. Hold on to this user manual and make sure it is available for service personnel.

Model name: Jøtul Gas Atra 740 SS

Serial no.:

Purchase date:

Name of installer:

Fuel type:

Was the stove converted?:

Notes:

Annual service - year 1 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 2 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 3 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 4 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 5 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 6 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 7 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 8 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 9 Service details:	Sign.:	Company:	Date:
---	--------	----------	-------

Annual service - year 10 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 11 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 12 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 13 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 14 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 15 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 16 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 17 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 18 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 19 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Annual service - year 20 Service details:	Sign.:	Company:	Date:
--	--------	----------	-------

Table of Contents:

Installation signature form	2
Installation and Use Instructions	4
1. Product Information	4
2. Flue Requirements	4
3. Fireplace Opening Requirements	4
4. Ventilation	5
5. Installation of Appliance Firebox	5
6. Installation of Gas Burner	5
7. Lighting and Controlling the Fire	5
8. IMPORTANT Appliance Control Notes	5
9. Commissioning	6
10. Servicing	6
11. Fault Finding	6
Instructions for Use	7
1. Important Notes	7
2. Important Appliance Control Notes	7
3. Lighting and Controlling the Fire	7
4. Servicing and Cleaning	7

Jøtul Gas Atra 740 Single Side

Decorative Gas Fuel Effect Appliance

**Countries of destination: AT, CH, DK,
ES, FI, FR, GB, GR, IE, IT, NL, NO, PT, SE.**

Independently Tested to EN613

**Only to be used with the gas type and
pressure stated on the data plate affixed to
the appliance.**

*Keep these instructions in a safe place for
future use.*

Jøtul UK Ltd
1 The io Centre
Nash Road
Park Farm North
Redditch
B98 7AS
UK

Jøtul France
3, chemin du Jubin
69570 DARDILLY
France

Jøtul AS
Box 1411
N-1602
Fredrikstad
Norway

Installation and Use Instructions

Important: Before proceeding with installation and use of this appliance, read these instructions carefully. Keep them in a safe place for future reference.

Gas appliances and chimneys require fresh air ventilation to work correctly and safely. **Only** use this appliance in a sufficiently ventilated space. Installation **must** be in compliance with the local and national rules in force. If in doubt seek expert local advice. Check ventilation regularly to make sure it is clear and unobstructed.

This appliance must only be installed by a competent person. In the UK this means a registered gas fitter **only**. Failure to observe this could lead to prosecution.

This appliance firebox is designed for use **only** with the glass panel in position. If the glass is damaged, loose or missing, the appliance could be dangerous due to leaking products of combustion so **do not** use in this condition. This appliance is intended for decorative use.

This appliance is a gas burning solid fuel effect appliance and as such it gets very hot in operation. No areas are designed to be touched during operation other than the control cover door and control knob itself. All other parts of the appliance are 'working surfaces' and get hot as a part of their function. Do not touch any areas other than the intended controls and always fix a proper fireguard in place when the presence of children, the elderly or infirm is likely. The glass itself is not a substitute for a fireguard and burns can occur from touching this working surface and the metal surrounds.

1. Product Information

Gas Type: Natural or LPG – see Data plate on appliance.

Natural Gas

Gas Type	Pressure	Gas Rate (m ³ /h)	CAT	NOx Class	Countries of Destination
G20	20 mbar	0.77	I2H	5	GB, IE, AT, CH, DK, ES, FI, GR, IT, NO, PT, SE
G20/G25	20/25 mbar	0.83	I2E+	4	FR
G25	25 mbar	0.83	I2L	4	NL

LPG

Gas Type	Pressure	Gas Rate (m ³ /h)	CAT	NOx Class	Countries of Destination
G31	37 mbar	0.29	I3P	3	GB, IE, CH, ES, FR, GR, IT, PT
G30/31	30 mbar	0.23	I3B/P	G30:3 G31:4	NL, NO, SE

Gas Connection: 8mm compression fitting.

Fuel Effect: Logs, Driftwood or Coals.

Efficiency: 58%

2. Flue Requirements

- A minimum 6" or 150mm diameter flue liner or rigid wall flue system is required for connection to this appliance.
- Minimum height of flue from top of appliance is 3m.
- The flue must be free of obstructions or dampers. Any damper must be removed or fixed permanently in the open position.
- If the chimney has been used for solid fuel or oil burning it must be thoroughly swept and completely cleaned before use.
- The chimney must be free from leaks or damage and continuous in its whole length. It must serve only one fireplace.
- Before installing to an existing flue liner, check that it has a draught by using a smoke match or similar. Investigate if there is no draught.
- No combustible materials are permitted in or near the flue or in contact with the flue liner or top of the firebox. Failure to comply with this requirement could lead to a fire hazard.

3. Fireplace Opening Requirements

- This appliance is only suitable for installation into NON-combustible fireplaces or builders openings.
- Minimum opening dimensions are 745mm wide, 590mm high and 460mm deep.
- Under no circumstances place the appliance on to carpet or any kind of combustible materials, including wood.
- Make sure that the room has adequate combustion and flue air supply. Purpose provided ventilation will normally be required in the UK for the proportion of the gas input that is above 7kW.
- Any combustible surrounding materials, including wallpaper, wooden shelves etc must be a sufficient distance from the appliance to prevent any risk of

overheating. Normally 6" or 150mm from the edge of the appliance casing will be sufficient. Check temperatures after several hours operation if in doubt about materials and their suitability. No curtains may be positioned above the appliance.

- The chimney must have suitable liner for direct connection to the appliance flue outlet spigot. Under NO circumstances may the appliance be fitted directly into a fireplace or chimney without **direct** connection to a proper flue pipe. Failure to observe this could cause abnormal operation of the appliance leading to a dangerous situation.
- The gas supply can be laid into the firebox from underneath the gas burner assembly (chased into the constructional hearth) as the firebox has an open base.

4. Ventilation

- For UK installation every 1kW above 7kW gas input, there must be 5cm² of additional purpose provided ventilation. For example: if the input is 8.15 kW (see data badge) this requires 1.15kW x 5cm² = 5.75cm² of permanent ventilation.
- This can be directly to outside air through an outside wall or through another room – but the next room must also have sufficient permanent ventilation to the outside. If in doubt consult an expert.

5. Installation of Appliance Firebox

- The gas supply must have a shut off valve near the appliance for maintenance purposes. A restrictor elbow is supplied with the appliance to use if one is not already present.
- Remove the glass panel (2 screws at bottom edge) and lift out the draught diverter assembly complete with flue spigot connector and place to one side.
- Insert the firebox into the opening and position correctly.
- Bring flue liner down into top of firebox through hole in top.
- Put gasket onto draught diverter flange and slide flue spigot and draught diverter assembly onto flue liner until properly engaged. Do not push liner down further than lower fixed stops in spigot.
- Use self-tapping screws to secure flue liner to flue spigot, making sure that the draught diverter part of the assembly is left clear for gases to enter the flue liner. This **MUST** be observed. Failure to screw the liner on properly or blocking the gap for products of combustion to enter the flue pipe will cause abnormal operation and may be dangerous.
- Push the whole assembly up into the hole in the firebox top and secure with screws provided.
- Complete the gas pipe for the burner assembly to the right hand side front underneath the firebox. Knockouts are provided in the sides of the firebox if necessary but the gas pipe can be brought in

underneath the fireplace base in most instances as the firebox bottom is open.

- Make good the wall surface up to the firebox or fit a trim. Always use non-combustible materials. Marble slips, metal or stone panels etc can be used to replace plaster around the firebox if required. Basic plaster and plasterboard do not usually have sufficient heat resistance to be used directly above the firebox.

6. Installation of Gas Burner

- Place burner into firebox. Angle control valve through the cut-out in the firebox base first and then lower down gradually, making the angle horizontal as it is lowered.
- **Purge Gas Pipe** to ensure any dust or debris is removed from it before connection to valve. The valve may be permanently damaged if this is not done and will be a chargeable replacement.
- Connect the gas pipe to the control valve using the internal compression nut and olive (compression ring) provided.
- Secure the burner to the firebox through the legs using the four M4 screws provided.
- Check for gas soundness and operation of ignition and pilot.
- Place pilot shield in front of pilot by hooking on to edge of burner tray.
- Install ceramics with instructions provided in pack.

7. Lighting and Controlling the Fire

- From the off position, press in and turn the knob anti-clockwise. A click will be heard from the piezo spark generator and the gas should ignite at the pilot. If it does not light first time, repeat until it does. When pilot is lit **hold** knob in for about 10 seconds to actuate the flame safety valve. If the pilot goes out, try again but hold in firmly for longer.
- Release valve knob and turn fully anti-clockwise to release gas to main burner. Once burner is lit the gas flow may be regulated by turning between low and high flame settings to the desired level.
- To turn back to pilot only, depress the control knob slightly first before selecting that position.
- To switch off completely press knob slightly and turn fully clockwise of off position.
- **Do not** relight burner for 3 minutes after switching off from hot condition.

8. IMPORTANT Appliance Control Notes

- This appliance is fitted with an Oxygen depletion sensing pilot unit which automatically shuts off the gas to the whole burner system if the oxygen levels in the room drop significantly. This can be caused by lack of ventilation or a blocked flue system which could cause dangerously poor combustion due to depleting oxygen levels.

- If the fire shuts down for any reason, wait a few minutes and try re-starting it. If the problem continues, immediately call an expert engineer to examine the installation.
- No part of the pilot or its air supply shall be modified in any way, or put out of operation, even by an installer/engineer. This can be very dangerous.
- Never use any other parts other than those officially supplied by Jøtul or its representatives to repair the oxygen depletion sensor pilot.
- As part of the flame supervision system, the fire will also shut down if the gas supply fails or the flames are extinguished for any reason. The valve will fail-safe and the appliance can be re-lit when conditions are restored.

9. Commissioning

- Close doors and windows and light fire on high. If there are extractor fans in neighbouring rooms, switch them on high and open interconnecting doors. Burn fire for 5 minutes and then test for spillage from draught diverter. Use a long smoke match tube from front of firebox top slot or push burning match right in until next to draught diverter. All smoke should be drawn into flue. Any escaping smoke indicates spillage.
- If spillage is indicated burn for another 10 minutes and re-test.
- If spillage is persistent, investigate flue pipe system or extractor fans etc and rectify problem. Minimum specification of flue must be 3m of 150mm (6") diameter liner or rigid pipe from the flue connector.
- A smell may be emitted from the fire when first used due to paint and materials curing. Burn the appliance on high and open doors and windows to burn this off as effectively and quickly as possible.
- Check gas pressure. This should be as per specified gas pressure on data plate. A test point is provided on the front of the gas control to check this. Check test point for leakage after testing.

10. Servicing

- This appliance should be serviced at least every 12 months to ensure safe operation.
- Any debris or soot which accumulates on the burner should be removed regularly.
- Clean the glass with a glass cleaner (or ceramic hob cleaner for stubborn marks) regularly. Simply remove the two screws at the bottom of the glass frame under the control cover and pull outwards and downwards gently to release the frame and glass. DO NOT use the appliance without the glass in place and undamaged. Failure to do this may create a dangerous situation.
- Remove fuel effect pieces and clean burner with vacuum cleaner.
- Disconnect gas supply and remove burner unit.

- Clean out air intake on venture tube under burner.
- Clean out air intake on front of pilot unit.
- Check and tighten all gas and thermocouple connections as required.
- Replace burner and reassemble firebed. Replace glass panel.
- Check ventilation is clear and unobstructed and meets with requirements.
- Recheck spillage as described in Commissioning section.

11. Fault Finding

1. No Spark:

- Pilot damaged or electrode too close or far from pilot head - adjust.
- Detached ignition lead – reconnect.
- Electrode insulator cracked – replace pilot assy.
- Soot or debris on pilot assembly – clean.
- Faulty ignition lead – replace valve assembly.

2. Spark Visible But Pilot Will Not Light:

- Check there is gas to appliance.
- Check restrictor elbow or isolation valve are open.
- Check pipe work is clean – including inlet connection.
- Pilot injector blocked – clean.

3. Pilot Flame Shortens Or Goes Out When Main Burner Lit:

- Insufficient gas supply to appliance – check inlet pipe work.
- Check for kinked bends or debris in pipes and connections.
- Check meter pressure setting.
- If no blockages or kinks are found then pipes may be undersized for the run to the appliance.
- **Note:** This is not an appliance fault.

4. Pilot Goes Out When Knob Released:

- Check tightness of thermocouple connections.
- Hold in knob for longer or more firmly.
- Debris in pilot pipe or jet – clean out.
- Replace pilot assembly.

5. Uneven or poor Flame Picture.

- Re-lay fuel bed.
- Clean out holes in burner board.
- Re-distribute embers (if fitted).
- Check gas pressure.

6. Blue Flames:

- Allow burner longer to warm up.
- Wrong gas pressure.

Instructions for Use

1. Important Notes

Before proceeding with use of this appliance, read these instructions carefully. Keep them in a safe place for future reference. Make a note of your installers name, address and registration number for future reference. This appliance is primarily intended for decorative purposes and not as a main heating unit.

Gas appliances and chimneys require fresh air ventilation to work correctly and safely. ONLY use this appliance in a sufficiently ventilated space. Installation MUST be in compliance with the local and national rules in force. If in doubt seek expert local advice. Check ventilation regularly to make sure it is clear and unobstructed.

This appliance must only be installed by a competent person. In the UK this means a registered gas fitter ONLY. Failure to observe this could lead to prosecution.

This appliance firebox is designed for use ONLY with the glass panel in position. If the glass is damaged, loose or missing, the appliance could be dangerous due to leaking products of combustion so **Do Not** use in this condition.

This appliance is a gas burning solid fuel effect appliance and as such it gets very hot in operation. No areas are designed to be touched during operation other than the control cover door and control knob itself. All other parts of the appliance are 'working surfaces' and get hot as a part of their function. Do not touch any areas other than the intended controls and always fix a proper fireguard in place when the presence of children, the elderly or infirm is likely. The glass itself is not a substitute for a fireguard and burns can occur from touching this working surface and the metal surrounds.

2. Important Appliance Control Notes

- This appliance is fitted with an oxygen depletion sensing pilot unit which automatically shuts off the gas to the whole burner system if the oxygen levels in the room drop significantly. This can be caused by lack of ventilation or a blocked flue system which could cause dangerously poor combustion due to depleting oxygen levels.
- If you suspect flue gases are coming into the room, call out your installer to check the safety of the installation.
- If the fire shuts down for any reason, wait a few minutes and try re-starting it. If the problem continues, immediately call an expert engineer to examine the installation.
- As part of the flame supervision system, the fire will also shut down if the gas supply fails or the flames

are extinguished for any reason. The valve will fail-safe and the appliance can be re-lit when conditions are restored.

3. Lighting and Controlling the Fire

- From the off position, press in and turn the knob anti-clockwise. A click will be heard from the piezo spark generator and the gas should ignite at the pilot. If it does not light first time, repeat until it does. When pilot is lit **hold** knob in for about 10 seconds to actuate the flame safety valve. If the pilot goes out, try again but hold in firmly for longer.
- Release valve knob and turn fully anti-clockwise to release gas to main burner. Once burner is lit the gas flow may be regulated by turning between low and high flame settings to the desired level.
- To turn back to pilot only, depress the control knob slightly first before selecting that position.
- To switch off completely press knob slightly and turn fully clockwise of off position.
- DO NOT relight burner for 3 minutes after switching off from hot condition.

4. Servicing and Cleaning

- The appliance must be serviced every 12 months minimum.
- Any debris or soot which accumulates on the burner should be removed regularly (only when cold!).
- If local regulations demand it, the flue liner should be cleaned as required.
- Clean the glass inside and out (only when cold!) with a glass cleaner (or ceramic hob cleaner for stubborn marks) regularly. Simply remove the two screws at the bottom of the glass frame under the control cover and pull outwards and downwards gently to release the frame and glass. **Do Not** use the appliance without the glass in place and undamaged. Failure to do this may create a dangerous situation.
- Remove fuel effect pieces (including embers where provided) and clean burner with vacuum cleaner.
- Re-lay fuel effect as shown in the diagrams. Do not re-lay in any other way as this can seriously affect operation.
- Clean paintwork and trims with a damp cloth only when cold! Do not use abrasive or chemical cleaners.

Cat.no. 221234
Draw.no. 4-4319-P00
Aug. 2004

Jøtul arbeider kontinuerlig for om mulig å forbedre sine produkter, og vi forbeholder oss retten til å endre spesifikasjoner, farger og utstyr uten nærmere kunngjøring.

Jøtul bemüht sich ständig um die Verbesserung seiner Produkte, deshalb können Spezifikationen, Farben und Zubehör von den Abbildungen und den Beschreibungen in der Broschüre abweichen.

Jøtul pursue a policy of constant product development. Products supplied may therefore differ in specification, colour and type of accessories from those illustrated and described in the brochure.

Jøtul vise sans cesse à améliorer ses produits. C'est pourquoi, il se réserve le droit de modifier les specifications, couleurs et équipements sans avis préalable.

Kvalitet

Jøtul AS arbeider etter et kvalitetssikringssystem basert på NS-EN ISO 9001 for utvikling, produksjon og salg av ildsteder. Vår kvalitetspolitikk skal gi kundene den trygghet og kvalitetsopplevelse som Jøtul har stått for siden bedriftens historie startet i 1853.

Qualität

Jøtul AS hat ein Qualitätssicherungssystem, das sich bei Entwicklung, Produktion und Verkauf von Öfen und Kaminen nach NS-EN ISO 9001 richtet. Diese Qualitätspolitik vermittelt unseren Kunden ein Gefühl von Sicherheit und Qualität, für das Jøtul mit seiner langjährigen Erfahrung seit der Firmengründung im Jahre 1853 steht.

Quality

Jøtul AS has a quality system that conforms to NS-EN ISO 9001 for product development, manufacturing, and distribution of stoves and fireplaces. This policy gives our customers quality and safety piece of mind as a result of Jøtul's vast experience dating back to when the company first started in 1853.

Qualité

Le système de contrôle de la qualité de Jøtul AS est conforme à la norme NS-EN ISO 9001 relative à la conception, à la fabrication et à la distribution de poêles, foyers et inserts. Cette politique nous permet d'offrir à nos clients une qualité et une sécurité reposant sur la vaste expérience accumulée par Jøtul depuis sa création en 1853.

Sistema di qualità

La Società Jøtul AS è in possesso di una sistema di qualità in conformità con il sistema NS-EN ISO 9001 per lo sviluppo e progettazione di nuovi prodotti, la loro fabbricazione e la distribuzione di stufe e caminetti. Questa certificazione, che assicura ai nostri clienti qualità e sicurezza, è il risultato della vasta esperienza che la Jøtul ha acquisito negli anni intercorsi dalla sua fondazione nel 1853.

Dette ildstedet er kontrollert av:
Dieses Produkt ist geprüft von:
This product has been controlled by:
Ce produit a été contrôlé par :
Questo prodotto è stato controllato da:

Jøtul AS,
P.o. box 1411
N-1602 Fredrikstad,
Norway

Date:

Sign:

