



Montfort Mk II 1340502 Non Bolt in Baffle Removal

1. Open door
2. Remove ash pan
3. Remove fuel retainer
4. Remove rear vermiculite firebrick, pull bottom out first
5. Lift & remove both side bricks
6. Ensure that steel baffle is pushed fully to rear casting just above fire grate level
7. Pull cast fire grate fully forward until front lip fits into door recess
8. Place hands under fire grate & lift rear of grate (this may require leverage under the rear of the grate) whilst pushing/sliding front of grate along side casting supports
9. When fire grate is nearly in the vertical position, push right hand side of grate to rear of stove whilst bringing left hand side forward
10. Drop left hand side of fire grate into ashpan recess & remove through door aperture
11. Grip rear steel baffle with fingers in corner cut off's & thumbs halfway up steel back plate
12. Flex bottom of baffle off cast lip
13. Drop bottom of baffle into ashpan recess & bring bottom edge of baffle towards the door aperture
14. Remove baffle square to stove and remove completely
15. Replace as in reverse



Heat Products Ltd