

Product: DV-2520 Cassette

No	Part Number	Description
1	DV-03.00323.000	
2	DV-03.00320.002	
3	DV-02414.0	Back Plate
4	DV-03.05215.000	Ashpan
5	DV-02.06106.000	
6	DV-03.06105.000	
7	DV-08301	Inner Back Plate
8	DV-02.09327.001	
9	DV-03.09361.002	Insulated Bottom Plate
10	DV-03.13616.000	
11	DV-03.13617.000	
47	DV-03.15732.005	
48	DV-02.15733.000	
49	DV-03.15606.000	Dimmer Switch
50	DV-03.22001.000	
51	DV-GL61	Glass
52	DV-37305.2	Glass Retainer
53	DV-04.26422.000	10mm x 3mm Self Seal Rope
54	4946	6mm Rope Seal
55	4981	8mm Rope Seal
56	DV-S27218.0	Door Catch
57	DV-27506	Wooden Door Handle
58	DV-03.30120.000	
59	DV-03.30109.000	
60	DV-03.32005.005	
61	DV-32204	Damper Rod
62	DV-03.27226.002	Ashpan Tool

No	Part Number	Description
63	DV-03.37324.005	
64	DV-02.37820.000.X21	Airgrill
65	DV-37901.0	Bottom Air Slider
66	DV-02.37932.000	
67	DV-03.40001.000	
68	DV-03.46527.041	
69	DV-56306	Grate Support
70	DV-03.58410.007	
71	DV-03.58411.007	
72	DV-03.00335.002	Flue Exit Convector Box
73	DV-61106	Grate Section
74	DV-03.61301.100	
75	DV-03.64611.000	
76	DV-03.66010.000	
77	DV-68203.0	Thermostat
78	DV-02.69118.005	
79	DV-02.69139.000	
80	DV-03.71314.005	
81	DV-03.73005.000	
82	DV-03.73006.000	
83	DV-76110	Baffle Plate
84	DV-03.77034.002	
85	DV-03.79142.000	
86	DV-03.79143.000	
87	DV-03.79534.005	
88	DV-02.37811.000	
89	DV-03.30109.000	
91	DV-03.00702.000	