

4. Spare parts

Spare partlist

So certain parts of your stove must be replaced, use only parts manufactured by Franco Belge.

When ordering spare parts, specify **the stove type** and **serial number**, including the **colour index** (on the guarantee or identification plate), **the name** of the part and **the part number**.

Example : Stove "Belfort", ref. 154 03 05, Top plate 352136.

N°	Codes	Description	Type	Qty
1	303718 EF	Blanking plate		01
2	352136 EF	Top plate		01
3	327801	Clamp		01
4	306290 EF	Back wall.		01
5	240303	Support.		01
6	100102	Clamp		01
7	202820	Support.		01
8	243506	Supplementary diverter		01
9	243404	Draught diverter		01
10	310823 EF	L. side panel.		01
11	310737 EF	R. side panel.		01
12	359818 EF	Front plate		01
13	110404	Hinge pin	6X30	02
14	189713	Screw	M8X30	01
15	134258	Bushing		01
16	300118 EF	Leg		04
17	300480	Base		01
18	124412	Strut	M8X45	01
19	276007	Descriptive plate.		01
20	122204	Winged nut.	M8 BN213	01
21	307440 EF	Fuel retainer		01
22	188798	Glass.		01
23	181632	Rope	DIAM 6	0,90 m
24	259015	Fixing plate		04
25	142881	Gasket		04
26	181614	Ceramic rope.	DIAM. 9,5	1,94 m
27	309997 EF	Main door		01
28	189825	Screw.	M 5X6.	01
29	301541 EF	Door lock.		01
30	100917	Cam pin		01
31	189849	Screw	M 6X16	01
32	327902 EF	Ash pan guide		01
33	105540	Burner NG		01
34	142883	Gasket		01
35	106040	Block gas		01
36	188321	Pilot NG		01
37	139637	Injector NG.		01
38	72812	Coals kit		01
39	109727	Moulded coal		01
40	109728	Triangle coal.		01
41	149985	Coal matrix.		01
42	105006	Rope	DIAM 15MM	1,05 m
43	181617	Rope	15X2	2,00 m
44	202827	Support filters front		01




Figure 4 - Spare parts view