

## 4. Spare parts

When ordering spare parts, specify the **stove type** and **serial number**, including the **colour** index (on the guarantee or identification plate), the **name** of the part and the **part number**.

**Example :** Wood stove "Basque", ref. **134 14 02**, colour **Y**, top plate **352173 60**.

N°	Code	Description	Type	Qty
1	100951	Axle		02
2	101060	Sliding door axle		01
3	101809	Ring		02
4	109332	Wiring system		01
5	134107	Glove		01
6	134253	Bushing		02
7	134705	Pin	6x45	01
8	134714	Pin		01
9	134758	Pin	4 x16	01
10	134760	Pin	5X20	01
11	142316	Gasket	7x3	0,44 m
13	166035	Spring	13x40	01
14	179042	Thermostat		01
15	181607	Ceramic rope	Ø 9,5	2 m
16	181632	Gasket	Ø 6	4,50 m
17	188508	Fan		02
18	188852	Refractory glass	743X418	01
19	189446	Screw	M5X08	04
20	222579	Flue baffle		01
21	189825	Screw		01
22	232005	Closing		01
23	958602	Driving bar		01
24	248321	Slide plate		01
25	259050	Fixing plate		01
26	271016	Bracket		02
27	301830	AB Handle		01
28	303214	AB Knob		01
29	303881	AB Flue collar	Ø 180	01
30	306202	AB Back wall		01
31	309230	Wood grate		01
32	310220	AB Side panel		02
33	319732	AR Grate support		01
34	320832	Sliding door		01
35	324013	AB Fuel retainer		01
36	324114	AB Fuel retainer		01
37	330015	AB Hearth plate		01
38	331115	AB Main door		01
39	331702	Ash pan		01
40	352173	AB Top plate		01
41	359828	AB Front plate		01
42	400106	Axle		01
43	970112	Left support ventilator		01
44	970111	Right support ventilator		01
45	808001	ED Handle		01
46	900983	Complete sliding door		01
47	305715	AB Supplementary grate		01
48	307442	AB Fuel retainer		01
49	989035	Complete door		01
50	988533	Fan complete		01




Figure 12 - Spare parts view

A = 134 14 02 R    B = 134 14 02 C    C = 134 14 02 Y

Nº	Code	Description	A	B	C	Qty
1	101070	Axle	A	B	C	04
2	109552	Leg	A	B	C	04
3	188508	Fan	A	B	C	02
4	913301	Base plate	A	B	C	01
5	201818	AY Top plate	A	B	C	01
6	202116	AY Supplementary top plate	A	B	C	02
7	207326	Back panel	A	B	C	01
8	912452	Side panel			C	02
8	912453	Side panel		B		02
8	912454	Side panel	A			02
9	217237	Shell top	A	B	C	01
10	923301	Square	A	B	C	04
11	970108	Left support	A	B	C	01
12	970105	Right support	A	B	C	01
13	956500	Fixing plate	A	B	C	02
14	275617	Casing support	A	B	C	01
15	970112	Left heat shield	A	B	C	01
16	970111	Right heat shield	A	B	C	01




Figure 13 Spare parts view