

## 4. Spare parts

When ordering spare parts, specify the stove type and serial number, including the colour index (on the guarantee or identification plate), the name of the part and the part number.

Example : Lorraine wood stove, Ref. **134 10 02 Y**,  
Base **300455 60**.

N°	Code	Description	Type	Qty
1	100956	.. Axle		01
2	110405	.. Hinge pin	6x35	02
3	134749	.. Pin	4x20	01
4	142301	.. Adhesive rope		0,85 m
5	142336	.. Gasket	300x10x3	01
6	157924	.. Descriptive plate		01
7	158541	.. Handle		01
8	166003	.. Spring	11x15	01
9	181604	.. Ceramic rope	10x4	1,00 m
10	181615	.. Ceramic rope	Ø 12	3,14 m
11	188728	.. Ceramic glass	375x190x5	01
12	189103	.. Screw	27x8x6	01
13	205330	.. Back panel		01
14	221200	66 Striking plate		01
15	224022	.. Ash-pan		01
16	260537	.. Heat shield		01
17	300105	59 B.L or F.R.leg		02
18	300217	59 B.R. or F.L. leg		02
19	300455	60 Base		01
20	301515	66 Door lock		01
21	301742	.. Air damper		01
22	302141	.. Top plate		01
23	303718	.. Blanking plate		01
24	303827	59 Flue collar	Ø 139	01
25	305009	.. Side wall		02
26	305114	.. Back wall		01
27	306215	.. Back wall		01
28	307416	.. Fuel retainer		01
29	309215	.. Wood grate		01
30	309825	.. Front plate		01
31	309933	.. Main door		01
32	310711	.. R. side panel		01
33	310811	.. L. side panel		01
34	319707	.. Grate support		01
35	323210	.. Flue baffle		01
36	327801	.. Clamp		01
37	407202	60 Glass retainer		01
38	415504	60 Poker		01
39	808001	60 Hand tool		01
42	72406	.. Coal kit		01
43	308710	.. Coal grate		01
44	224023	.. Ash-pan		01

