



200G/L COOKER

RAYBURN 200G/L COOKER

Bubble Number	Cat. No.	Description	Product Code
1	R1775	MOB PREP FOR TWIN C/P INS CVRS RHO - O/T SPINDLE	RS5R0-19152
2	R1193	NAME BADGE	RG4M35613
3	A1651	HINGE SPINDLE MOD.74 & RAY TWIN INS. COVERS	A94M42886
4	A2087	CIRCLIP ANDERTON E1500 250S FOR HINGE PIN	KCLP26203
5	R2409	INSULATING COVER COMP - CHROME - GRUB TYPE	RG9M312012COMP
6	R1711	BRACKET FOR INSULATING COVER HANDLE	RS4M23090
7	R1076	DOME WASHER FOR COIL HANDLE	KW8R27740
8	R2176	COIL HANDLE (CHROME PLATED)	RG4M310136
11	R1020	SEALDOME - MARSEAL	JMAR20555
12	R1614	INSULATING COVER LINING PLATE	RO2E140773
13	R1481	HOT PLATE MK2	RO5M0-7624
14	R2803	HOTSPOT BAFFLE	RG5M310000
15	R2804	HOTPLATE RESTRICTOR BRACKET	RG2M310010
16	R1037	NO.4 THERMOSEAL ROPE FOR HOT PLATE 60"	JTHR20389-60IN
18	A1744	HANDRAIL BRACKET C/W BOLTS & NUTS-MOD 74-	A89M3-9124COMP
19	R1724	CHROME PLATED HANDRAIL N/T	RG4M312141
21	R2820	PIPE TOP OVEN VBNT 3/4" BSP X 62MM LONG	A54M37960
22	R1713	STAY BUTTON	RS4M24420
23	R1066	CORNER STAY NUT 1/8"	KNUT53090
24	R1760	CORNER STAY ROD ONLY	RS4M44080
25	R2805	CORNER STAY ROD	RG4M310048
27	R2806	BRACKET ASSEMBLY - CORNER STAY	RG1M310112
29	R1084	TIME SWITCH PROG EP4001 C/W INSTRUCTIONS	RG1M310064
31	R1902	BACK PLATE -WHEN NO BOILER-	RS5M63
32	R2807	CONTROL PANEL	RG1M310152

RAYBORN 200G/L COOKER

Bubble Number	Cat. No.	Description	Product Code
33	R2460	LH SIDE PANEL	RG2V110051
34	R2162	COOKER CONTROL KNOB	RG4M310044
35	R1047	CLIP TO SUIT BOILER KNOB	KCLP26296
37	R2433	BUSH STRAIN RELIEF SR-6P10 H/L	GG4M24197
38	R1236	THERMOSTAT RANCO C26-P0258	RG4T310061
40	R2808	FLUE DUCT ASSEMBLY	RG1M310019
41	R2809	BURNER CHAMBER ASSEMBLY	RG1M310018
44	R2219	PILOT BURNER (HONEYWELL)	RG4M310057
74	R2810	BURNER HOUSING DUCT ASSEMBLY	RG1M310020
75	R2811	BURNER HOUSING BLANKING PANEL	RG1M310021
76	R2812	TERMINAL MOUNTING BRACKET	RG2M310066
77	R2813	TERMINAL BLOCK COVER	RG2M310046
78	A1108	3-WAY TERMINAL BLOCK METWAY 500A	AB4M45676
79	R2814	3-WAY TERMINAL BLOCK INSULATOR	RG4M310047
81	R1095	HOT PLATE BAFFLE SEALING PLATE	RG2M91745
82	R2815	FIREBOX RH SIDE	RG5M310002
83	R2824	THERMOSTAT PHIAL GUIDE ASSEMBLY	RG1M310013
84	R2711	BRACKET - REAR STAT PHIAL LOCATION	RG1M311001
85	R2815	THERMOSTAT PHIAL LOCATION BRACKET	RG2M310014
86	R2826	BRACKET FIRE BOX SIDE FIXING	RG2M3123004
87	R2827	BURNER CHAMBER FRONT APERTURE PANEL	RG2M310088
88	R2690	BRACKET - BASEPLATE	RG2M311231
89	R2829	SIMMERING OVEN LH SIDE PLATE	RG5M310006
91	R2828	BASE PLATE FILLER PIECE	RG2M310097
92	R2479	BASE PLATE	RG5M313072

Issue date: 16/10/96
Issue number: .00

RAYBORN 200G/L COOKER

Page 2

RAYBORN 200G/L COOKER

Bubble Number	Cat. No.	Description	Product Code
95	R1479	DIVERTER HOOD ONLY	RO5E8608
96	R2277	DIVERTER BAFFLE	RG5M310009
97	R1473	DIVERTER SPIGOT & BASE	RO5E1-19929
99	R1806	HOB PROTECTION PLATE	RS5M0-19753
101	R1844	OVEN TOP FLUE GUIDE-SIDE-R.H.O.	RS5M288
102	R2816	TOP PLATE TOP OVEN (6B)	RG5M310104
103	R2818	FRONT FLUE FEATHER	RG5M310118
104	R2398	OVEN TOP VENT FOR R.H.O. COOKERS	RS50103
106	R1868	OVEN TOP FLUE GUIDE -NEXT OUTLET- R.H.O.	RS5M31B1
107	R1916	OVEN SIDE -REMOVABLE-	RS508-RH
108	R1915	OVEN SIDE -FIXED- R.H.O.	RS507-RH
109	R1845	OVEN TOP FLUE GUIDE -NEXT FIRE- R.H.O.	RS5M298
110	R1913	TOP OVEN BACKPLATE	RO5M340460
111	R2819	OVEN REFLECTOR DUCT ASSEMBLY	RG1M310012
112	R2820	PIPE TOP OVEN VENT 1/4" BSP X 62MM LONG	AB4M37960
113	R2597	TOP OVEN BOTTOM PLATE 4-RH	RS50300015
114	R2540	SIMMERING OVEN REMOVABLE LH SIDE C/F & B/F	RG5M310005
115	R2817	SIMMERING OVEN BOTTOM PLATE	RG5M310004
116	R2801	SIMMERING OVEN RH SIDE	RG5M310003
117	R2785	SIMMERING OVEN BACK PLATE C/F & B/F	RO5M340533
118	R2821	SUPPORT BRACKET SIMMERING OVEN	RG2M310016
119	R2822	RETAINING BRACKET SIMMERING OVEN	RG2M310017
120	R2412	SIMM. OVEN INS FRAME ASSY C/F & B/F	RG1M310015
121	R2365	FRONT PLATE C/W DOORS VE	RG9E500-2GDO
122	R1734	OVEN DOOR CATCH/FIREDOOR STUD	RS4M34120

Issue date: 16/10/96
Issue number: .00

RAYBORN 200G/L COOKER

Page 3

RAYBURN 200G/L COOKER

Bubble Number	Cat. No.	Description	Product Code
123	A1950	OVEN DOOR NYLON WASHER 5/8" X 5/16" X 1/32"	KWSR53500
124	R2823	GASKET BARLAN "A" X 4MM	JGSG310194
126	R1260	OUTER BURNER DOOR COMPLETE	RG9E310008COMP
127	R1089	WARMING OVEN DOOR LINING	RG2M310115
128	R2817	SIMMERING OVEN BOTTON PLATE	RG5M310004
129	R2209	SIMMERING OVEN DOOR	RG5E310116
129	R2164	BOTTOM OVEN DOOR COMPLETE	RG9E310116COMP
130	R2061	DOOR HANDLE C/W SCREWS	RS9M31530COMP
130	R1539	SET OF 3 DOOR HANDLES	RG9M31530SET3
131	R2432	OVEN THERMODIAL BI-METAL ROUND	RS4T301075
132	R1147	GASKET THERMODIAL PERM AF 2000	RG4M30412
133	R2284	OVEN DOOR STRIPPED	RS5E519
133	R1917	FIREDOOR DRIP EDGE	RS5V83746
133	R1972	OVEN DOOR -NO THERMODIAL- R.H.O.	RS9E519N-T
134	R1705	SLAGWOOL MATTING FOR OVEN DOOR	RS4M20490
135	R2931	OVEN DOOR LINING	RO2M320198
137	R2119	SET OF 4 NYLON DOOR WASHERS	RS9M53500SET4
138	R1618	PLAIN OVEN SHELF	ALL MODELS RO2M340757
139	R2573	OVEN GRID SHELF	ALL MODELS RS4M300070
140	R1004	MEAT TRAY	EMTY47744
141	R2218	NAME BADGE "RAYBURN"	RO4M330013
146	R1761	OVEN STAY ROD	RS4M44111
147	R1102	SIDE PLATE LH FOR R.H.O. COOKER	RG2V41993
152	R2719	GROMMET REEVITE REF.NO.PV56A	RG4M31217
161	R2190	CABLE CLAMP	RG4M26192

Issue date: 16/10/96
Issue number: .00

RAYBURN 200G/L COOKER

Page 4