



Exploded View Scan 65




Exploded View Scan 65

High Top 65-5/6/7/8/9/10


Top outlet
50043583 soapstone



Rear outlet
50043584 soapstone



Top plate steel
65-9/10
51051728 Black
51051729 Grey



Gasket
Type AA
51037833

Window
51050566



(Baking) Thermometer
50006014



Plate for oven
51050567




Mantle back
51050560 Black
51050561 Grey



Set supp. soapstones
E+F+G+H
50049249



Front stones
E or F
51050384



Side stones
G or H
51050385

Standard kit
without windows
A+B+C+D
50043585

Soapstone left A
without windows
51048202

Soapstone right C
without windows
51048201

soapstone
B or D
51044375



Mantle side left
51050562 Black

Mantle side right
51050563 Black




Air indicator plate
51050497 Black
51050498 Grey

Set supp. soapstones
E+F+G+H
50049249



Front stones
E or F
51050384




Side stones
G or H
51050385

Standard kit
with windows
A+B+C+D
50043586

Soapstone left A
with windows
51048206

Soapstone right C
with windows
51048204

soapstone
B or D
51044375



Heat storage stones
51049926

Mantle side left
with windows
51050564 Black

Mantle side right
with window
51050565 Black

