


ASHLING OIL DHW EXP VIEW C/W PARTS & BOM CODES



- | | |
|--|--|
| 1. Leg (Short) - B00077AXX | 20. Ashling Boiler Assembly - L00347CXX |
| 2. LH Side Panel - B00122BXX | 21. Flue Outlet 125 Dia. - Q00660AXX |
| 3. Front - B00299CXX | 22. Control Knob - U00086AXX |
| 4. Hob - B00303BXX | 23. Grommet - V00100AXX |
| 5. Base - B00304CXX | 24. P-Clip (RS 543-361) - V00111AXX |
| 6. RH Panel - B00499BXX | 25. Annealed Copper Pipe - V00472BXX |
| 7. 5" Draft Regulator - F00553AXX | 26. Scrubber - V00473BXX |
| 8. Combustion Chamber - F00554DXX | 27. Oil Valve - V00570AXX |
| 9. Valve Support Bracket - F00590BXX | 28. Timber Handle - U00009AXX |
| 10. Valve Control Rod - F00592BXX | 29. Door Latch - V00055AXX |
| 11. Cable Protection Box - F00593BXX | 30. Front Door - B00110BXX |
| 12. Heat Shield Bracket - F00665AXX | 31. Door Catch - V00048AXX |
| 13. Heat Shield - F00666BXX | 32. Door Glass - T00005AXX |
| 14. Ignition Probe C/W Leads - G00206AXX | 33. Glass Retaining Clip - L00344AXX |
| 15. Ignition Switch - G00273AXX | 34. Door Grill - B00111BXX |
| 16. Transformer C/W Leads & Bracket - G00209BXX | 35. Sump Cover - B00305AXX |
| 17. Heat Shield Assembly - L00272FXX | 36. Front Ashtray - B00114AXX |
| 18. Combustion Chamber Roof Assy - L00282EXX | 37. Sump Cover Bracket - F00273AXX |
| 19. Burn Pot Assembly - L00318CXX | |