

1. Burner Control Plate
2. Burner
3. Pressure Differential Link Pipe
4. Damper Axle
5. Damper Axle Knobs
6. Cover Plate to Damper Rod
7. Viewing Glass Frame
8. Viewing Gasket Side
9. Viewing Glass
10. Viewing Glass Gasket
11. Combustion Chamber Front Panel
12. Boiler
13. Boiler Top Baffle Side
14. Stay Rods
15. Boiler Top Baffle Back
16. Combustion Chamber Front Baffle
17. Boiler Baffle
18. Oven Baffle
19. Combustion Chamber Back Baffle
20. Combustion Chamber Corner Baffle
21. Oven Baffle Lever
22. Burner Gasket
23. Burner Gasket Plate
25. Oven Protecting Plate
26. Outside Oven Side Plate LH
27. Inside Oven Side Plate LH
28. Top Oven Back
29. Back Panel S.I.
30. Base
31. Bottom Grill
32. Front Insert
33. Burner Door Mesh
34. Burner Door Sealing Rope
35. Burner Door
36. Door Knob
37. Door Catch
38. Insulating Cover
39. Control Panel
40. Fire Door
41. Fire Door Sealing Rope
42. Fire Door Mesh
43. Cleaning Door To Front
44. Front Frame
45. Oven Door Knob
46. Door Hinge
47. Towel Rail Bracket
48. Warming Oven Door Knob
49. Towel Rail
50. Capillary Bracket
51. Locking Pin
52. Capillary Covering Side
53. Capillary Covering Bottom
54. Label
55. Warming Oven Side
56. Top Oven Side RH
57. Flueway
58. Flueway Blanking Plate
59. Side Panel RH
60. Oven Door Inner Panel
61. Oven Door Sealing Rope
62. Oven Glass Filler Piece
63. Oven Door Sealing rope
64. Dial
65. Cleaning Plate Retaining Clip
66. Oven Top Extension
67. Warming Door Sealing Rope
68. Oven Door

69. Warming Door
70. Side Panel LH
71. Insulation Wool
72. Warming Oven Base Plate Front
73. Oven Shelf
74. Warming Oven Top
75. Top Oven Bottom Plate
76. Oven Baking Tin
77. Oven Top
78. Bottom Oven Back
79. Steam Escape (Only on Balanced Flue)
80. Front Top Flue Guide
81. Fixed Damper
82. Back Top Flue Guide
83. Cleaning Plate Sealing Rope
84. Hob
85. Stay Nut
86. Cap to Stay Nut
87. Cleaning Plate to Hob
88. Hob Sealing Rope
89. Hotplate
90. Hotplate Pads
91. Hotplate Sealing Rope
92. Warming Oven Base Plate Rear
93. Hotplate Cover Hinge
94. Plate to Hotplate Cover
95. Hotplate Cover
96. Handle to Hotplate Cover
97. Venturi Collar
98. Exhaust Bend
99. Gasket to Bend
100. Cleaning Door to Bend
101. Cable Gland Nut
102. Rubber Grommet

103. Warming Oven Side LH
104. High Limit Thermostat
105. Basil
106. Boiler Control Knob
107. Oven Control Knob
108. Basil (Oven)
109. Thermo Block
110. Oven Thermostat

111. Capillary Cover
112. Boiler Thermostat
113. Neon Indicator (2 off)
114. Limit Re-set Cover
115. Gas Shut Off Valve
116. Mains Gas Tap
117. Gas Pipe Clamp

