


GIP


# BOSKY COOKER

## ELECTRICAL CONNECTION



S2 - 100m.  
 Take S1 - S3 100m  
 Take col. wires out.  
 Thread S3 100m in!  
 Connect six wires to block  
 Red, white, Blue, Brown.

# New Bosky Wiring Diagram



New Bosky Wiring Diagram

June 2001